



HOW TO APPLY COLLIDESCAPE PATTERNS

Step 1: Preparing Surface

Ideal surface temperature range for application: 55°F to 85°F.

Surface must be clean and free of dirt, grease, and wax. Use glass cleaner or soapy water to clean your surface.

Tools Needed:

- Glass Cleaner / Cleaning Solution
- Clean Towel
- Squeegee
- Masking Tape

Step 2: Spacing

Use masking tape or a grease pencil to mark out even spacing of the pattern onto the glass; Patterns must not be wider than 4" horizontally to be effective. If spacing guides are provided, tape to the inside of the glass top and bottom as an alignment aid.

Clear Dots: make a mark every 4.75" (3/4" width of dot + 4" spacing)

White/Tinted Dots: make a mark every 4.5" (1/2" width of dot + 4" spacing)

Step 3: Measure

Tape a dot pattern strip into position with masking tape in 3 positions: at the top center and bottom, making sure your vertical line of pattern is straight by measuring from the window edge. NOTE: make sure each row of dots starts at the same position relative to the top of the window for a constant, professional finish.

Step 4: Create Hinge

Once you have your CollidEscape Pattern placed in the right location, remove the masking tape at the top, and lay back the top half of the strip. This will create what we call a hinge. Make sure to firmly press down your masking tape at the center so that it will hold.

Step 5: Remove Backing

Remove the top half of the exposed wax liner backing paper and tear off, so that the top quarter of the pre-spacing tape adhesive and dot adhesive are exposed.

Step 6: Application

Gently tack the strip back up onto the glass, now using the exposed adhesive to bond to the glass, rubbing the length of tape with liner removed down with your fingertips. Firmly bonding dots and pre-spacing tape to the surface of the window.

Now remove the center and bottom tape, and remove the remaining wax liner backing paper, and align and tack the remainder of the pattern strip.

Step 7: Step and repeat

Repeat steps 4-6 until the window is covered with a 4" gap between each vertical row of dots.

Step 8: Remove Prespacing Tape

After the CollidEscape Pattern has been applied, remove the prespacing tape by peeling it back slowly at a 180 degree angle to the surface, leaving the dots below bonded in place on the glass. Double check that no dots lifted or remain on the spacing tape (extras provided)